

Installing the Firmware Update

Download the Firmware Update to your computer and move the file to a known location. Format a thumb drive so there is no data on it. Unzip the zipped file and copy the seven files to the root directory of the formatted thumb drive.

The thumb drive should now have these seven files in the root directory:

Name	Type	Compressed size	Password ...	Size	Ratio	Date modified
EBOOTND.nb0	NB0 File	57 KB	No	256 KB	78%	10/20/2020 1:22 PM
EBOOTSD.nb0	NB0 File	58 KB	No	256 KB	78%	10/20/2020 1:22 PM
Logo.bmp	BMP File	19 KB	No	1,126 KB	99%	7/21/2017 1:21 PM
MLO	File	15 KB	No	84 KB	83%	10/20/2020 1:22 PM
NK.bin	BIN File	56,435 KB	No	89,720 KB	38%	10/20/2020 1:26 PM
Release.txt	Text Document	1 KB	No	1 KB	0%	10/20/2020 3:04 PM
XLDRNAND.nb0	NB0 File	11 KB	No	128 KB	92%	10/20/2020 1:22 PM

With the AccuFIT 9000 powered off, insert the thumb drive into one of the “A” type USB ports in the back of the AccuFIT 9000. Press the “ON” button and allow the instrument to complete its warmup and self-check.

A screen will appear asking you if you want to upgrade to the firmware on the thumb drive.

“Copy from USB Flash Drive?”

Select “Yes”

Allow the data to be copied to the AccuFIT 9000, and when this is complete, the instrument will ask if you want to re-start. Press “Yes” and remove the thumb drive.

After this is complete tap “Setup” and then “Device Info” and check that the correct updated version shows in the “App. Rev.” field.